



Circuit diagram and examples of connection


NPN output




NPN output with analog supply



PNP output





PNP output with analog supply




Dimensional information

► Body




► Installation

1. This product has two inlet pressure ports, select the one most convenient for installation.
2. Please plug the unused inlet port with supplied port plug. Use seal tape to prevent pressure leak.



[Measure Unit : mm]

► Mounting bracket



► Panel type

